


MODEL 230.4

Shown on model 230.4 without code (P99)
Special model "AMG Black Series"

- 1 Lever
2 Locking lever



P88.40-2200-06

	Open		
⚠ Danger!	Risk of injury caused by fingers being pinched or crushed when removing, installing or aligning hoods, doors, trunk lids, liftgates or sliding roof	Keep body parts and limbs well clear of moving parts.	AS00.00-Z-0011-01A
1	Pull lever (1) to release engine hood		
2	Pull handle of safety hook (arrow) and open engine hood	⚠ Do not fold windshield wiper arms toward front to prevent damaging the paint on the engine hood.	
	Move to upright position		
3	Actuate locking lever (2) on left engine hood hinge and raise engine hood to vertical position		
	Close		
4	Actuate locking lever (2) on left engine hood hinge and press down engine hood until locking lever (2) arrests		
5	Completely close engine hood		
6	Check locking function of engine hood catch		